

CLIMBING

KIT SRT

SRT ACCESSORY

SIMPLE AND EFFICIENT



www.ftc-tree.com



A SET TO PRACTICE SRT ACCESS (SINGLE ROPE TECHNIQUE).

TECHNICAL DATA

FOOT LOOP

- Upper strap length: adjustable from 1 to 1.30 m (3.2 to 4.2 ft)
Lower strap 0.35 to 0.6 m (13.8 to 23.6 in).
- Weight 135 g (4.8 oz).
- Metal adjustment buckles.
- Can be used with all the chest ascenders on the market.

NECK LOOP

- Flat elastic band, 25 mm large (1 in).
- Polyester/cotton.
- Plastic adjusting buckle.
- Sold with carabiner.

STORAGE BAG

- Outer fabric: Ripstop / Lining: Polyester.
- Capacity - 1 L.
- Drawstring with toggle and end stopper.

CONNECTION OF THE UPPER AND LOWER STRAPS TO THE ASCENDER



Upper strap: use the blue strap with a girth hitch



Lower strap: use the black strap with a girth hitch

SRT NECK LOOP AND ITS CARABINER

ELASTIC SHOULDER STRAP

Chest ascender * and its carabiner *

SRT BAG


Knee ascender *

LOWER STRAP

Foot ascender *

Adjustable foot loop * and its carabiner *

* Elements not included.



PERFORMANCES

A good set for SRT: a foot loop and an adjustable neck loop in their storing pouch, little space and very light. The FOOT LOOP can be fixed on the shoe with a carabiner, or the shoe slipped into the adjustable loop. It is easy to use and can be adapted to any knee ascender as well as the climber's size.

No need to take off the helmet to put the SRT NECK LOOP on or take it away, it keeps the knee ascender in upright position during the ascent. All is stored away in the SRT BAG, attached to the back of the harness. With its stiff rim, it is easy to find the gear stored inside, yet the lining drawstring secures it.

Foot loop clipped to the shoe with a carabiner or directly with the adjustable loop

